

Model 101

Listed Dimensions: 31" L x 26" W x 21" H



Sample Interior Spacing

Height	Le	ngth	Width	
2″	2	24″		
8″	2	22"		
16"	1	10"		
Diameter Sizing				
Height		Diamete	r	
2"		24" Dia	24" Dia	
8"		18" Dia		
16"		10" Dia		



IDEAL CONCEALING APPLICATIONS: -Septic Vent Pipes up to 16"-18" in Height -Water Well Casing up to 16"-18" in Height -Small Pumps, Compressors and Blowers -Small Backflow or Irrigation Valves



Dekorra Rocks do taper in length and width as height increases. Any concerns in sizing for a specific item can be discussed with a Dekorra Customer Service Rep at 888-635-8585, sizearock@dekorraproducts.com along with a photo of the specific application and dimensions.





ASSE STANDARD 1060 CLASSIFICATION

- **Class I** Freeze protection. DekoRRa Rock Enclosures Class I and I-V shall have a minimum thermal resistance value of R-8 and a positive means of heat. DekoRRa Rock Enclosures have been designed and constructed to maintain a minimum internal temp. of 40[®]F.
- Class II Freeze retardant. DekoRRa Rock Enclosures Class II and II-V shall have a minimum thermal resistance value of R-8. DekoRRa Rock Enclosures have been designed and constructed to be installed in minimum external temperatures of 33[®]F.
- **Class III** Non Freeze protection. DekoRRa Rock Enclosures Class III and III-V are designed and constructed to provide system security for components when freezing temperatures are not a consideration.

INSTALLATION INSTRUCTIONS:

- If Class I-V Heat required, installations will require GFI protected power mounted at least 6" above all water discharge ports per local code regulations.
- 2. Pour concrete pad per measurements provided or if mounting to ground, level area where enclosure is to be installed.
- 3. If installation requires self regulated heat tape, install per instructions securing to piping and valve. Place insulated pouch over valve and piping assembly.
- Place rock over device. Verify that rock does not interfere with device. Insert included stakes for soil installation. For concrete installations see optional concrete installation instructions.

CONCRETE ANCHOR INSTALLATIONS

- Drill hole with same diameter as anchor of sufficient depth. Clean drilled hole of dust and debris.
- 2. Place washer and nut onto threaded anchor as required.
- 3. With nut, washer and set pin in place insert anchor through rock flange column and into concrete base.
- Using a proper size hammer set pin with several sharp and square strikes on head of pin until pin is flush with top of threaded anchor.





